## PANEL DESIGNS

There are two options to create clamp load between the two attached panels:



All dimensions are in inches.							All dimensions are in millimeters.					
Q	Thread Code	Max. Swaged Diameter	Max. Swaged Height H	Min. Hole Attached Panel With Bump Out	Max. Hole Attached Panel Without Bump Out	METRIC	Thread Code	Max. Swaged Diameter	Max. Swaged Height H	Min. Hole Attached Panel With Bump Out	Max. Hole Attached Panel Without Bump Out	
	256	.182	.058	.182	.187		M2.5	4.93	1.5	4.93	5.06	
Ē	440	.205	.056	.205	.210		M3	5.44	1.45	5.44	5.56	
z	632	.229	.059	.229	.234		M4	6.3	1.5	6.3	6.43	
⊃	832	.259	.062	.259	.264		M5	7.44	1.47	7.44	7.57	
	032	.280	.059	.280	.285		M6	8.28	1.42	8.28	8.41	
	0420	.343	.057	.343	.348							

© 2010 PennEngineering.

**PennEngineering**®



North America: Danboro, PA USA • E-mail: info@pemnet.com • Tel: +1-215-766-8853 • Fax: +1-215-766-0143 • 800-237-4736 (USA Only) Europe: Galway, Ireland • E-mail: europe@pemnet.com • Tel: +353-91-751714 • Fax: +353-91-753541 Asia/Pacific: Singapore • E-mail: singapore@pemnet.com • Tel: +65-6-745-0660 • Fax: +65-6-745-2400 Shanghai, China • E-mail: china@pemnet.com • Tel: +86-21-5868-3688 • Fax: +86-21-5868-3988

> Visit our PEMNET<sup>™</sup> Resource Center at www.pemnet.com Technical support e-mail: techsupport@pemnet.com